

TOHNICHI COMPACT DISPLAY

MODEL CD 5

INSTRUCTION MANUAL



Before using this product, please read this instruction manual carefully for your safety use. If you have any questions, contact your nearest distributor or TOHNICHI.

For your safety

To the user

Read these operating instructions carefully before use. For any questions, contact a Tohnichi authorized distributor or Tohnichi office. Keep these instructions for future use.

Safety symbol

This symbol indicates attention is required for your safety. When this symbol appears in these instructions, pay particular attention for your safety concerns. Take preventative measures according to the written message for appropriate operation and management.



Signal Words

A signal word accompanies the safety symbol, which indicates the level of cautions on safety of people and the appropriate use of the equipment.

Signal words are classified into 3 levels: "danger", "warning" and "cautions" by the degree of risk.

- 「△Danger」 : Imminent danger which may cause serious damage.
- 「△Warnings」 : Potential danger which may cause serious damage.
- 「△Cautions」 : Potential danger which may hinder ordinary operation but may not lead to serious damage.

⚠ Warnings

- ① Stop using the product immediately when you find something not normal in the product such as smoke or strange smell. It may cause an electric shock or a fire. Turn off the power immediately and pull out the AC adapter and contact your nearest Tohnichi distributor or TOHNICHI.
- ② Do not disassemble or modify the product.
It may degrade the safety level or shorten product life.
- ③ If water or some foreign particles comes inside the product, stop using.
It may cause an electric shock or fire.
- ④ Do not plug in and out with a wet hand.
It may cause an electric shock.
- ⑤ Do not use the voltage other than listed voltage (AC100V – 240V $\pm 10\%$).
Using other voltage may cause an electric shock or a fire.
- ⑥ Do not use a damaged AC adapter.
It may cause an electric shock or fire.
When handling the power cord, pay attention to the following.
Do not modify or damage the cable.
Do not pull it, put a heavy object, or pinch it.
Do not force to bend or twist it.
Do not use other electric power cords than those designated.
Do not use the cable for other electric products.
- ⑦ Handle AC adpter with care.
A wrong use of the product may cause a fire.
Do not plug in when dust or foreign particles are on the adapter.
Plug in fully to the root and firmly.

- ⑧ When pulling out the AC adapter, make sure to hold the AC adapter to not damage the cable, which may cause a fire.
- ⑨ Do not place it on a tilted plate or place with a vibration to prevent possible falling of the product.
- ⑩ Do not place it where combustible liquid or gas exists.
It may cause an electric shock or a fire.
- ⑪ Use only the designated product and accessories to prevent possible injuries.

⚠ Cautions

- ① Avoid place with high humidity, or dust, or place subject to direct sun light and where temperate fluctuate widely.
- ② Plug out the AC adapter and clean it periodically.
- ③ When not using the product in a long period, make sure to plug out the cable.
- ④ When moving the product to other places, make sure to turn off the power and plug out all the related cables beforehand. Do not apply physical damage or vibration to the product. It may cause a fire, electric shock or product malfunction.
- ⑤ Check for damaged part.
Check all the conditions and proper operation of the product before use.
For damaged part, contact your nearest distributor or TOHNICHI for repair.

Note

- ① Use the voltage AC100V– 240V range only.
Use the enclosed AC adapter.
- ② Do not use the product in conditions not specified in this manual.
- ③ Do not disassemble or modify the product.
- ④ Check the product and settings before use.
- ⑤ Keep from water and oil to avoid malfunction.
- ⑥ Do not drop the product. It may break.
- ⑦ Connect the product to the torque sensor in proper way.
- ⑧ Conduct periodic checkup.
- ⑨ Check zero on the display before measuring.

If strange smell or fire occurs, stop using the product immediately and place it in a safe place. Contact Tohnichi immediately to seek advice.

■ Contents

For your safety	1
1. Outline	4
2. Features	4
3. Components	4
4. Name of each part	5
5. Explanation of each mode	8
6. Functions and operation	9
▪ Auto zero adjustment	
▪ Judgement function	
▪ Auto judgement	
▪ Saving measured data	
▪ Auto memory/reset function	
▪ Statistical processing	
▪ Deleting measured data	
▪ Over torque alarm	
7. Connection	11
▪ Connecting with torque sensor	
▪ How to connect to terminals	
▪ Connecting to RS232C	
8. Calibration	15
▪ Regarding calibration	
▪ Equivalent input calibration	
▪ Calibration using actual weight	
▪ Calibration using load applied by sensor-equipped torque wrench	
9. Various settings and operation	28
▪ Upper limit value	
▪ Lower limit value	
▪ Measuring direction	
▪ Auto judgement timer	
▪ Auto memory/reset timer	
▪ Detect external input isgnal	
▪ Communication output format	
▪ Torque unit in printer output	
▪ Baud rate	
▪ Data length	
▪ Parity	
▪ Flow control (RTD/CTS)	
▪ Memory mode	
▪ Calibration (clockwise/counterclockwise)	
▪ Reset setting (default setting)	
10. Example use	37
11. Interface to external device	40
12. Option	44
13. Error message	44
14. Specifications	45

1. Outline

CD5 compact display is a digital display to show values measured by the strain gauge sensor.

2. Features


- ① Judgement function
Upper and lower limit of the measured value can be set in advance.
If the measured result is within the OK range, it shows in blue display, and when it is out of the range (upper or lower), it informs in red display.
- ② Enhanced visibility
The black mask LCD is applied in the display to improve visibility.
- ③ Data memory
Measured data can be saved up to 1000pc.
- ④ Data transfer to external device
CD5 is equipped with RS232C (compliant) connector, which allows the data transfer to external devices such as PC, sequencer, and the dedicated printer.
- ⑤ International voltage range
AC100V-240V \pm 10% power voltage covers use in almost any place of the world.
- ⑥ CE marking
With CE marking attached, it can be used in EU legitimately.

3. Components

- | | | |
|-------------------------------------|-------|-----|
| ① Body (Display unit) | | 1pc |
| ② AC adapter (BA-6) | | 1pc |
| ③ Power converting adapter (Type C) | | 1pc |
| ④ Instruction manual | | 1pc |


4. Name of each part

4-1 Display and operating board



- ① Torque display: Displays the measured torque value.
- ② Counter/Upper value display: Shows the memory counter or the upper limit value.
- ③ Lower value display: Displays the lower value.
- ⑤ RUN mode (RUN): When in RUN mode, ▼ appears above here.
- ⑥ PEAK mode (PEAK): When in PEAK mode, ▼ appears above here.
- ⑦ Auto judgement (A.C): When auto judgement is selected, ▼ appears above here.
- ⑧ Setting process (SET): During the setting or calibration process, it shows ▼ appears above here.
- ⑨ Setting lock (LOCK): When the lock switch on the back panel is turned on, ▼ appears above here.
- ⑩ Setting change (CH): When CH.SW signal is input (CH2 selected), ▼ appears above here.
- ⑪ Counter backward key (down key)
Push this key to see the previous data. Keep it pushed to fast-forward.
- ⑫ Counter forward key (right key)
Push this key to see the next data. Keep it pushed to fast-forward.
- ⑬ Memory key (MEM key)
Save the measured data and proceeds to the next counter.
- ⑭ Mode key (MD key)
Keep pushing this key for 2 seconds in RUN mode, and it changes to the setting mode. Pushing this key in PEAK mode shows sample quantity, max/minimum/average values respectively.
- ⑮ Clear key (C key)
It clears the measured data in PEAK mode.
Auto zero adjustment will be effected in RUN mode.

4-2 Power and input/output



- ① INPUT: Connector for sensor cable.
- ② Power jack (12V, 1A): Connect the enclosed AC adapter (BA-6) to this terminal.
- ③ Power switch: Turn power ON/OFF.
- ④ Lock switch: It prevents accidental change of the setting by the lock function. When it is ON, ▼ appears on LOCK in the display.
- ⑤ External terminals: Use these terminals to connect to external devices.
Signal output terminal: Output no voltage output signal between COM1 and each terminal.

COM1: Common terminal (HI, OK, LO) for output signal.

HI: Outputs HI signal

OK: Outputs OK signal

LO: Outputs LO signal

● Signal input terminal: Shunt (short-circuit) each terminal to COM2.

※ Do not apply voltage. Input signal must be 0.1 sec or longer.

COM2: Common terminal for input signal (RESET, CLEAR, COMP, CH. SW).

RESET: It saves the measured data in PEAK mode, and send the counter to the next. When connected to external device such as PC, the measured data will be transferred to the device in both PEAK and RUN mode.

CLEAR: Clears the displayed value.

Auto zero function will be effected in RUN mode.

COMP: Judgement will be given to the measured value.

It displays in blue when the judgement is OK, and red when the judgement is NG (LO/HI).

CH. SW: Changes the setting.

When CH. SW and COM2 are shunted, ▼ appears at CH of the display.

※ When changing the channels, all the measured data will be deleted.

● Analog output terminal

AGOUT: Amplifies the sensor input, and output as voltage output (0 to $\pm 11V$)


GND: GND terminal to analog output.

※ Analog output voltage is not calibrated (not adjusted in accurate ratio against torque value). Check the output voltage by applying static torque load using the calibration device, etc

- ⑥ RS232C: Use this terminal to connect to the printer or PC (D-SUB9 pin male).


4-3 Display

- PEAK mode




- PEAK mode

When upper/lower limit values are not set, upper left corner of the display shows the memory counter and the measuring channel.



- Judgement in process

When the judgement result is OK, it displays in blue, and when it is NG (LO/HI) is shows in red.



5. Explanation of each mode

① Measuring mode

● RUN mode

Set the memory counter to 0000 to set it to RUN mode. In RUN mode, the displayed torque value increases as torque is applied, and returns to zero as it is released. (Counter clockwise load will be shown in negative figures.)

● PEAK mode

Set the memory counter to 0001 – 1000 to set it to PEAK mode. In PEAK mode, the displayed torque value increases as torque is applied, and maintains the maximum value (peak value) as torque is released. If you apply torque in counter clockwise direction, torque value is displayed in negative figures and maintains the peak value in the same way.

② Memory mode

● 1000 data mode (default setting)

It can save up to 1000pc of data in the memory.
Judgement result is also output through RS232C.

● 99 data mode

It can save up to 99pc of data in the memory.
In this mode, RS232C output format is compliant with that of CD42 (previous version).

6. Functions and operation

① Auto zero adjustment

In either RUN mode or PEAK mode (RUN display), do either of the following to effect auto zero function.

- Press C key
- Input CLEAR signal
- Input CLEAR command through RS232C
- Turn on the power

Range of auto zero

Auto zero adjustment works only when the following conditions are met. When the displayed value is out of range, it shows Err9.

PEAK mode: lower than 5% of the max measured value

(lower than 50% when calibrated by actual weight using torque wrench sensor).

RUN mode: Sensor input is lower than ± 1 mV/V

When turning the power on: Sensor input is lower than ± 1 mV/V

Err9 display: Sensor input is lower than ± 1 mV/V

● How to remove Err9

Set the connected sensor at no load condition and press C key.

* If Err9 disappears by the above operation, CD5 is working properly.

If Err9 remains on the display, it needs to be repaired. Contact TOHNICHI or its authorized distributor.

② Judgement function

Set OK range (upper/lower limit value) and it judges whether the measured torque is within the set range. The display turns blue when the judgement result is OK, and red when it is out of the range (LO = too low, HI = too high). At the same time, no voltage contact signal will be output from the terminal LO, OK, HI respectively.

Judgement result

LO: Measured value < lower limit value

OK: Lower limit value \leq Measured value \leq Upper limit value

HI: Upper limit value < Measured value

Judgement in PEAK mode

When upper/lower limit are set, do either of the following to give judgement.

- Input COMP signal
- Input command from RS232C
- When auto judgement is effected

Judgement in RUN mode

When upper/lower range is set, input COMP signal to give judgement.

③ Auto judgement function

When judgement function is on in PEAK mode, judgement will be automatically given if the peak is not renewed within the set time (0.1 to 5.0 sec selectable). If you set it to 0.0 second, auto judgement function will be cancelled.

④ Saving measured data

Measured data can be saved up to 1000pc in PEAK mode when either of the following is commanded.

- Press MEM key
- Input RESET signal
- Send command from RS232C
- When auto memory function is in effect

* After the memory is full (1000pc), the counter will be returned to 0001 and the old data will be overwritten by the new one.

⑤ Auto memory/ Reset function

Auto memory/Reset function saves the measured data automatically after the set timing (selectable from 0.1 – 5.0 seconds) and proceeds to the next counter. If auto judgement function is in effect at the same time, Auto memory/Reset will be effected only when the judgement is OK. If you do not want to use Auto memory/Reset function, set it to 0.0 second.

⑥ Statistical processing

Sample quantity (n): Shows the number of measured data in the selected range.

Max value (HI): Shows the max value of the selected range of data.

Minimum value (LO): Shows the minimum value of the selected range of data.

Average value (Av): Shows the average value of the selected range of data.

⑦ Deleting measured data

- Delete one piece of data

Use down/right key to select the data to delete and push C key.

- Delete selected range of data

Use down/right key to select the last memory counter of the selected range and press MD key. The display shows "Stt". Then, use down/right key to select the first memory counter of the selected range and press MD key. While the display shows either "n", "HI", "Lo", or "Av", press MD key and C key at the same time. The selected range of data is now deleted.

- Delete all the saved data

First, turn the power off. Press C key as you turn the power, then all the saved data will be deleted (calibration value and settings remains intact).

* Before deleting the data, make sure to check if the data is no longer needed.

⑧ Over torque alarm

When the measured torque exceeds 110% of the max capacity, the display starts to blink and the buzzer goes off for warning. Also, when input value exceeds the sensor's rated voltage (capacity), the bar icon on the display shows blinks for alarming. See the following table

Sensor rated value	bar icon display
below 1.3mV/V	above 1.7mV/V
1.3mV/V to 3.0mV/V	above 3.15mV/V

⑨ Switching calibration settings

2 kinds of calibration values can be registered and they can be switched around depending on the situation. This function is useful either when you use 2 different torque sensors to connect to CD5 or when you want to register 2 settings in one torque sensor.

Shant (Short-circuit) CH. SW and COM2 to switch to 2CH and ▼ appears at CH of the display.

* Switching the channel will delete all the previous data.

* Auto zero adjustment will be effected when switching the channels. Make sure no load is applied when switching.


7. Connection

7-1 Connecting with torque sensor


Connect CD5 with the torque sensor using "INPUT" jack on the backside of CD5. Use TOHNICHI standard connector only. If you have to use an extension cable, make sure to use 4-core shielded cable and follow the instructions below.

* Recommended connector: PRC03-12A10-7M10.5 (TAJIMI ELECTRONICS CO., LTD)

If the displayed torque value is not stable, attach a clamp filter on the connecting cable.




Connection of CD5 and torque sensor



Wiring diagrams of 4-core shielded cable

7-2 Connecting to terminals


Terminals on the backside of CD5 are aligned as the following illustration.



● How to connect to terminals

CD5 applies user-friendly clamp style connecting so it is simple and easy.

- ① Skin off 11 - 12mm tip of cable and twist it a little to put together.
- ② Push in 凸part with a screwdriver and insert the tip of the cable into the hole.
- ③ Release the screwdriver and put it back.
- ④ Pull the cable gently and check it is clamped securely.




11~12mm

Applicable wires are

Single wire: $\phi 0.4 \sim 1.2\text{mm}$ (AWG26-16)


twisted wire: $0.2 \sim 1.25\text{mm}^2$ (AWG24-16)

A wire in the cable $\phi 0.18$ 以上



● Connecting to output signal terminal

Output circuit is relay contact output. COM1 is the common use of the output signal terminal.



* Notice on output wire arrangement

Load on the contact output must be within the rated current..

(Relay output: DC30V1A, AC125V, 0.5A). This capacity is based on the resistance load. In some cases, between rated current and rush current may exist a large gap.


Following table shows the typical relations between rated current and rush current.

load type	rush current	load type	rush current
resistance load	about same of rated current	mercury lamp load	about 3 times of rated current
solenoid load	10-20 times of rated current	naturium load	1-3 times of rated current
motor load	5-10 times of rated current	condenser load	20-40 times of rated current
incandescent light bulb load	10-15 times of rated current	trance load	5-15 times of rated current


When switching on/off induced load, it may generate inverse voltage, which may damage contact point and shorten its life. Refer to below examples and take measures to protect contact point.

circuit sample		application		features/others	how to choose elements
		AC	DC		
CR method		※ △	○	When load is by the timer, leaked current through cr may cause error. * When using AC voltage, load impedance must be lower than that of cr.	c, r should be roughly ranged as below: c: contact current 1A ⇒0.5-1(μF) r: contact voltage 1V ⇒0.5 -1 (Ω) c is effective in controlling electricity release when on/off of contact point. R controls current for the next time. Check in your own experiment. c should use 200 - 300V voltage resistance. For AC circuit, use AC condenser.
		○	○	When load is relay or sorenoid, recovery time may delay. When power source voltage is 24 or 48V, it is recommended to connect between the loads. When 100V - 200V, connect between contact point.	
diode method		×	○	The energy accumulated in the coil will be released to the coil in the form of current by the parallel diode, and consumed as Joule heat by the resistance of inductive load. This method takes more recovery time than cr method.	Voltage resistance of the diode should be 10 times or more than the circuit voltage and the current for the right direction should be more than the loaded current .If the circuit voltage is not so big, resistance voltage should be 2 - 3 times that of the source voltage.

- Connecting external input signal
External input circuit input signals by shunting (short-circuit) respective input terminal and COM2.



- Do not apply voltage to the input circuit. Doing so may damage the internal circuit.



- Connecting analog output
This output terminal takes out the analog voltage in proportion to the sensor signal.
* Use shielded cables for wiring.
* Do not shunt (short-circuit) AGOUT and GND. Doing so may cause malfunction.
* Do not apply voltage from external source. It may cause breakdown.

7-3 Connecting to RS232C

Use the dedicated cable(no.383) to connect CD5 with PC. Refer to the following wiring diagram.

CD5 output signal internal equivalent circuit			PC (D-SUB9S female)		
PIN	signal	contents	PIN	signal	contents
1			1	DCD	carrier direct
2	RXD	receive data signal	2	RXD	receive data signal
3	TXD	send data signal	3	TXD	send data signal
4			4	DTR	no connection
5	GND	ground	5	GND	ground
6			6	DSR	no connection
7	RTS	send request signal	7	RTS	send request signal
8	CTS	send permit signal	8	CTS	send permit signal
9			9	NC	no connection
frame	shield		frame	shield	

- * Serial cross cable (KR-ECL9-2, SANWA supply) is also applicable.

8. Calibration

8-1 Regarding calibration

Calibration refers to the adjusting procedure between CD5 and a torque sensor in accurate proportion. There are 3 kinds of calibration method as below.

● Equivalent input calibration

This calibration method can be processed just by inputting the rated output value (mV/V) and the maximum measuring value without using any actual weight. Rated value of the sensor ranges from $\pm 0.5\text{mV/V}$ to $\pm 3\text{mV/V}$.

Example) Calibration of TCF100N can be processed by inputting the "rated output value 2mV/V " and "maximum measuring value 100N.m ". Gain value will be automatically calculated.

* A label is attached on TOHNICHI torque sensor, on which the rated output value is listed. The maximum measuring value differs depending on the torque sensor.

● Calibration using actual weight

This calibration method applies actual stable weight and input its value by key operation. It can be applied when you cannot find the rated output value of the torque sensor, and more accurate calibration is possible. Actual loading range is $\pm 1\text{mV/V}$ to $\pm 3\text{mV/V}$.


● Calibration using load applied by sensor-equipped torque wrench

This calibration method inputs the peak value applied by a sensor-equipped torque wrench. This method is used only when calibrating sensor-equipped torque wrenches. Maximum load range is 0.1mV/V to 3mV/V . Only clockwise operation applicable with 1/2000 resolution.

calibration method	equivalent input calibration		calibration with actual load	calibration with sensor-equipped torque wrench
sensor rated value range	+0.5 to +1.0mV/V, -0.5 to -1.0mV/V	+1.0 to +3.0mV/V, -1.0 to -3.0mV/V	+1.0 to +3.0mV/V, -1.0 to -3.0mV/V	+0.1 to +3.0mV/V
max measuring value	10000	25000	25000	10000
max resolution	1/2000	1/5000	1/5000	1/2000
measuring direction	both direction/clockwise/counter clockwise		both direction/clockwise/ counter clockwise	clockwise
peak starting torque	over 5% of max measuring value		over 5% of max measuring value	over 50% of max measuring value
auto zero range	below 5 % of max measuring value		below 5% of max measuring value	below 50% of max measuring value, or below 1mV/V

* When purchasing a torque sensor and CD5 at the same timing, calibration will be processed at TOHNICHI before shipping.

8-2 Flow chart for calibration



8-3 How to proceed equivalent input calibration

This calibration method can be processed just by inputting the rated output value (mV/V) and the maximum measuring value without using any actual weight.

⚠ Notice: When purchasing a torque sensor and CD5 at the same time, calibration will be processed at TOHNICHI before shipping.

Example)


In case of TCF100N "rated output value 2mV/V, maximum measuring value 100Nm.
Check the wiring connection between CD5 and the sensor.

- ① Set the memory counter to "0000".



- ② Switch off the lock on the backside of CD5 (Setting cannot be changed without unlocking).

When the lock is cancelled, ▼ above LOCK disappears.




- ③ Set it to calibration display

Press C ⇒ MEM ⇒ MD key in this order.

After above key operation, "CAL-E" flashes on the display, which is the setting mode (If already calibrated, the display may show either "CAL-E", "CAL-r", or "CAL-P".)


- ④ Select calibration method

Use down/right key to select "CAL-E" (=Equivalent input calibration) and press MEM to confirm.



CAL-E: Equivalent input calibration
CAL-r: Calibration by actual weight
CAL-P: Calibration using sensor-equipped torque wrench

The display shows as below and "0." flashes.




⑤ Setting sensor rated value (clockwise)

Input sensor rated value.



Example) Set the rate output value to 2.000mV/V.


1) Press down key twice and set it to 2.



2) Check the set value and press MEM to confirm.

As you press MEM key, it proceeds to the next setting(decimal point).


⑥ Selecting the decimal point



Example) Set the decimal point to "000.00"

1) Press right key twice.

Use right key to move the decimal point position one by one.
0.0000→00.000→000.00→0000.0→00000




2) Check the set position and press MEM to confirm.

As you press MEM key, it proceeds to the next setting (Max value).

⑦ Setting the maximum measuring value


Set the maximum value of the torque sensor.



Example) Set the max value to "100.00".

1) Press down key 9 times.


Use right key to select digits (selected digit flashes) and down key to select number (counting from 9, 8, 7 ⇒0).



2) Check the set value and press MEM to confirm.

As you press MEM key, it proceeds to the next setting (smallest digit setting).

⑧ Setting the smallest digit (1 digit)




Displayed value is the smallest digit value. To change the value, press down key.

* Refer below for resolution for CD5. Setting beyond below values is not applicable.


Sensor rated value $\pm 0.5 - 1.0\text{mV/V}$ Resolution 1/2000

Sensor rated value $\pm 1.0 - 3\text{mV/V}$ Resolution 1/5000



Check the set value and press MEM key to confirm.

Press MEM key, and it returns to the measuring condition on RUN mode. Setting is now complete. Switch the lock on to prevent accidental change of settings.



8-4 Calibration using actual weight

This calibration method inputs the value loaded by the actual weight. More accurate calibration is possible. Refer to the following procedures.


Example) TCF100N, max measuring value: 100Nm

* Check the wiring condition between CD5 and the sensor before proceeding.


- ① Set the memory counter to "0000".



- ② Switch off the lock on the backside of CD5 (Setting cannot be changed without unlocking). As you switch it off, ▼ above LOCK disappears.



- ③ Set it to calibration display
Press C ⇒ MEM ⇒ MD key in this order.
After above key operation, "CAL-E" flashes on the display, which is the setting mode (If already calibrated, the display may show either "CAL-E", "CAL-r", or "CAL-P").
- ④ Select calibration method
Use down/right key to select "CAL-r" (=Calibration using actual weight) and press MEM to confirm.




CAL-E: Equivalent input calibration
CAL-r: Calibration by actual weight
CAL-P: Calibration using load applied by sensor-equipped torque wrench

The display shows as below and "0." starts to flash.



⑤ Selecting the decimal point




Example) Set the decimal point to "000.00".

1) Press right key twice.


Press right key to move the digit rightward.
0.0000 → 00.000 → 000.00 → 0000.0 → 00000

2) Check the position and press MEM key.



Set the position of the decimal point and press MEM key to confirm. Zero on the biggest digit starts to flash as shown below.

⑥ Setting the maximum measuring value



Example) Set max value to "100.00".


1) Press down key 9 times.

press down key to set the value
(down count 9, 8, → 0)

2) Check the set value and press MEM key.



⑦ Setting the smallest digit value (1 digit)




Displayed value is the smallest value. To change, press down key.

* Refer below for resolution for CD5. Setting beyond below values is not applicable.


Sensor rated value $\pm 0.5 - 1.0\text{mV/V}$ Resolution 1/2000

Sensor rated value $\pm 1.0 - 3\text{mV/V}$ Resolution 1/5000




Check the set value and press MEM to confirm.

After the above procedure, the display changes as below and an arbitrary number appears.




⑧-1 Set the torque sensor to the calibration device and apply a training weight. Apply the max measuring weight as training weight.

⑧-2 Remove the training weight and press C key. Set the calibration lever and wire and press C key again.




Check the display shows "0".

⑧-3 Apply the maximum measuring weight again
(The display may show values irrelevant to the loaded torque value).




(The above figures are not torque value.)



For reference : calibration of torque sensor

⑧-4 Press MEM key to register the actual loading value. The display returns to the measuring condition on RUN mode, and shows the maximum torque value. Check the displayed value matches your setting.




After the above procedure, the display returns to the measuring mode (RUN mode).




⑧-5 Remove loading and check it returns to "0".

After checking, remove the calibration equipment.



Now, calibration is complete. Put the lock switch back to prevent accidental setting change.



8-5 Calibration using load applied by sensor-equipped torque wrench

Use this method for calibrating a sensor-equipped torque wrench.

Set the torque wrench on the torque tester and apply torque for 3 times.

Calibration is processed based on the average value of this 3-time measurement results. Highest resolution is 1/2000.



Example) Calibrating CSPD140N3 "torque setting 100N.m"

* Check the correct wire connection between CD5 and the torque wrench before proceeding further.

- ① Set the memory counter value to "0000".




- ② Switch off the lock on the backside of CD5 (Setting cannot be changed without unlocking). As the lock is cancelled, ▼ above LOCK on the display disappears.




- ③ Set it to calibration display
Press C ⇒ MEM ⇒ MD key in this order.
After above key operation, "CAL-E" flashes on the display, which is the setting mode (If already calibrated, the display may show either "CAL-E", "CAL-r", or "CAL-P".)

- ④ Select calibration method
Use down/right key to select "CAL-E" (=Equivalent input calibration) and press MEM to confirm.




CAL-E: Equivalent input calibration
CAL-r: Calibration by actual weight
CAL-P: Calibration using sensor-equipped torque wrench

After the above key operation, "0." flashes on the display.



⑤ Selecting the decimal point




Set the decimal point to "000.00".

1) Press right key twice.

As you press right key, the decimal point moves rightward.


0.0000 → 00.000 → 000.00 → 0000.0 → 00000



2) Check the set value and press MEM key to confirm.

As you press MEM key, it proceeds to the next setting (max measuring value).

⑥ Setting the maximum measuring value



Example) Set the max measuring value to "100.00".

1) Press down key 9 times.


Press down key to set the value (9, 8 ⇒ 0)



2) Set the value and press MEM key to confirm.

As you press MEM key, it proceeds to the next setting (smallest digit).

⑦ Selecting the smallest digit (1 digit)



Displayed value is the minimum value. To change it, press down key.


* Refer below for resolution for CD5. Setting beyond below values is not applicable.

Sensor rated value $\pm 0.5 - 1.0\text{mV/V}$ Resolution 1/2000


Sensor rated value $\pm 1.0 - 3\text{mV/V}$ Resolution 1/5000

Check the set value and press MEM to confirm.

After the above procedure, the display changes as below
(an arbitrary number appears).




- ⑧ Zero adjustment and calibration with actual weight.
- ⑧-1 Set the sensor-equipped torque wrench to the torque wrench tester and apply a training weight (set torque).
- ⑧-2 Remove the torque wrench from the torque wrench tester and press C key for both torque wrench tester and CD5. Check the displayed value returns to 0.




Check the display shows "0".



- ⑧-3 Set the torque wrench on the tester again and operate the torque wrench and press MEM key. Repeat this process for 3 times.
(The values shown on CD5 are irrelevant to the measured torque value).



After the above procedure, the display returns to a measuring mode (RUN mode). Remove the torque wrench from the torque wrench tester and check the display shows "0".



Calibration is now complete. To prevent accidental setting change, put the lock switch back on.



Slide the LOCK switch back to the original position.

9. Various settings and operation


Settings and their procedures are explained below.

9-1 List of setting items



	setting item	display	default	select
1	Upper limit value	HI	0	0 – max value
2	Lower limit value	Lo	0	0 – max value
3	Measuring direction	tUrN	botH	rIgHt/LEFt
4	Auto judgement timer	AC	0.0	0.1–5.0
5	Auto memory/Reset timer	Ar	0.0	0.1–5.0
6	Detect external input signal	EdgE	rISE	FALL
7	Communication output format	doUt	PC	Prn
8	Torque unit in printer output	Unit	Unit 1	Unit 2 ~ Unit 12
9	Baud rate	bPS	2400	4800/9600/19200
10	Data length	LngtH	7bit	8bit
11	Parity	PArtY	nonE	odd/EvEn
12	Flow control (RTD/CTS)	Flo	on	oFF
13	Memory mode	dCnt	1000	99
14	Calibration (clockwise/counterclockwise)	CAL	CAL1	CAL2
15	Reset setting (Default setting)	dFLt	dFLt-n	dFLt-Y

9-2 How to proceed settings


- ① Set the memory counter to "0000".




- ② Turn the lock switch off to enable setting change (Lock switch is on the back side of CD5). Check ▼ above LOCK on the display disappears.



- ③ Keep pushing MD key for 2 seconds or more until the buzzer goes off, then release it.
The display changes as below to set the upper limit value.



- Upper limit value setting (Default: 0)
Setting the upper limit value for judgement.
If you prefer no judgement, set it to "0"




Example) Setting to 55Nm

- ① Press right key 1 time (press right key to select digit).
- ② Press down key for 5 times (press down key to set the number).
- ③ Press right key 1 time.
- ④ Press down key for 5 times.
- ⑤ Check the value on the display and press MEM key to confirm.

It proceeds to lower limit value setting.

- Lower limit value (Lo) setting
Setting the lower limit value for judgement
If you prefer no judgement, set it to "0".




Example) Setting to 45Nm

- ① Press right key 1 time (press right key to select digit).
- ② Press down key for 6 times (press down key to set the number).
- ③ Press right key 1 time.
- ④ Press down key for 5 times.
- ⑤ Check the value on the display and press MEM key to confirm.

It proceeds to measuring direction setting.

- Measuring direction setting (Default: both)




Use right/down key to select from below.
Both: Clockwise and counter clockwise
rIghT: Clockwise only
LEFt: Counter clockwise only

Press MEM key to confirm and proceeds to the next setting.

● Auto judgement timer (Default: 0.0)

Setting timer for auto judgement.

Auto judgement timer conducts judgement automatically after the set timing.



It proceeds to the next setting.

Example) Setting to 0.5 second

- ① Press right key for 5 times
* Timer is settable every 0.1 sec for 0.1 ~ 0.5 sec range, and every 1.0 sec for 1.0 – 5.0 sec range.
- ② check the set value on the display and press MEM key to confirm.



● Auto memory/Reset timer setting (Default: 0.0)

Setting Auto memory/Reset timer

Auto memory/Reset timer saves the data automatically after the set timing and proceeds to the next counter.

When upper/lower limit value is set, auto memory/reset timer works only when the judgement is OK. When using this function and auto judgement timer at the same time, Auto memory/Reset must be longer than Auto judgement timer.

If you want to turn off this function, set it to "0.0".



It proceeds to the next setting.



Example) Setting to 1.0 sec.

- ① Press right key for 6 times.
* Timer is settable every 0.1 sec for 0.1 – 0.5 sec range, and every 1.0 sec for 1.0 – 5.0 sec range.
- ② Check the displayed value and press MEM to confirm.



● Detecting external input signal (default: rISE)

Selecting the detecting way of external terminal input signal(RESET, CLEAR, COMP)

rISE: Detecting by upward move of input signal



FALL: Detecting by downward move of input signal




Press MEM key to proceed to the next setting.

● Output format setting (Default: PC)

Setting output format for RS232C.


* To connect to sequencer, etc, select "PC".

PC: Output to PC



- ① Use right/down key to select PC or Prn.
- ② Check the setting and press MEM to confirm.

Prn: Output to Printer



It proceeds to the next setting.


● Baud rate setting (Default: 2400bps)

Setting baud rate for RS232C

* To connect to the dedicated printer (EPP16M2) select 2400bps.


* To connect to PC or sequencer, select the baud rate in line with their settings.

2400bps




- ① Use right/down key to select.
- ② Press MEM key to confirm.


4800bps



9600bps



19200bps



It proceeds to the next setting.


● Communication setting (Default: 7 bit)

Setting the data length for RS232C.

* Select 7 bit when connecting to the dedicated printer EPP16M2.

* When connecting to PC or sequencer, select the data length in line with their settings.

Data length: 7bit



① Use right /down key to select.

② Press MEM key to confirm.

Data length: 8bit




It proceeds to the next setting.

● Parity setting (Default: nonE)

Setting parity for RS232C communications.

* When connecting to the dedicated printer (EPP16M2), select nonE.


Parity: none




① Use right/down key to select.

② Press MEM to confirm.

Parity: odd



Parity: even



It proceeds to the next setting.


● Flow control setting (Default: on)

Choosing whether or not to enable RTS/CTS flow control (on: enable flow control, off: disable flow control).

* When sending a command to CD5 from external device, make sure to set it ON.


* When outputting data to the dedicated printer (EPP16M2), set it ON.

Flow control "ON"



- ① Use right/down key to select ON or OFF.
- ② Check the display and press MEM key to confirm.

Flow control "OFF"



It proceeds to the next setting.


● Memory mode (Default: 1000)

Choosing the capacity of data memory

1000: 1000pc of data


99: 99pc of data (communication format compliant with previous version CD42).

1000: 1000pc of data



- ① Use right/down key to select.
- ② Check the display and press MEM key to confirm.

99: 99pc of data



As you press MEM key, the display changes as below.




- * If you agree to delete all the previous data, press MEM key.
It proceeds to the next setting
(Clockwise/Counter clockwise calibration).

- * If you do not want to delete the existing data, press C key to cancel memory mode change.
It returns to previous display.




- Calibration (clockwise/counterclockwise) (Default: CAL1)
Choosing whether to calibrate clockwise and counter clockwise direction at the same time, or separately. (CAL1: both at one time / CAL2: separately)

Calibrating Clockwise/Counter clockwise at the same time



- ① Use right/down key to select.
- ② Check the display and press MEM to confirm.

Calibrating Clockwise/Counter clockwise separately



As you press MEM key, it proceeds to the next setting.


- Reset setting (Default setting)
Reset the setting to default
Saved data will be deleted but the calibration settings value remain intact.

Do not reset settings




- ① Use right/down key to select.
- ② Check the display and press MEM to confirm.



Reset setting to the default conditions.



As you press MEM key, it returns to a measuring display on RUN mode.



To prevent accidental change of settings, put the lock switch back.




9-3 Check and change the current settings

Follow the below operation to check the current settings or change them.

●Checking the current condition

- ① Set the memory counter to "0000".




- ② Push MD key for 2 seconds or more till the buzzer goes off.
The display shows the upper limit value (HI).



- ③ Press MD to check the current settings.

As you press MD key, the display shows the current settings in the following order respectively.

* () shows the number of times to push MD key.




* Press C key to cancel along the way.
It goes to a measuring display in RUN mode.

●How to change the current settings

- ① Set the memory counter to "0000".




- ② Press MD key for 2 seconds or more until the buzzer goes off. It proceeds to upper limit value settings.



- ③ Press MD key several times until it shows the setting you would like to change.
(Example) Changing Auto memory/Reset timer to 0.5 second

- ③-1 Press MD key 4 times as it shows Auto memory/Reset timer settings.




- ③-2 Unlock the LOCK switch.

Turn the lock switch on the back side of CD5 to enable setting change.


▼ above LOCK on the display disappears.




- ③-3 Use right/down key to set it to 0.5.



- ③-4 Press MEM key to confirm.



- ③-5 Put the lock switch back on.



- ③-6 Press C key to return to a measuring display on RUN mode.

10. Example use

Shown below is a typical use of CD5 connected to a sensor-equipped TOHNICHI product.

Example1) In case CD5 is connected to TCF100N to check tightening torque
(When the tightening completion signal cannot be taken)

Setting condition:

Judgement: Upper limit value: 55Nm

Lower limit value: 45Nm


Auto judgement time: 1.0 sec

Auto memory/Reset: 2.0 sec


Connection: Connect the torque sensor to "INPUT" of CD5.

Operation:

- ① As torque is applied, the peak value starts to increase.
- ② Auto judgement will be conducted if the peak value is not renewed within the set time frame.
 - In case of OK judgement
OK signal will be output when the displayed torque value is within the set range (between upper and lower value).
 - In case of HI judgement
HI signal will be output when the displayed value exceeds the upper limit value.
- ③ - in case of OK judgement
After releasing torque and reaching the set time, auto memory/reset will be activated. It saves the data and proceed to the next memory counter and reset.
 - In case of HI (= when it exceeds the upper limit value)
Measured data will be saved by pushing MEM key or inputting RESET signal. Measured data will be cleared by pushing C key or inputting CLEAR signal (When the judgement is HI, auto reset/memory will not work even after the set timing.)



Case 1: Judgement OK



Case2: Judgement HI

Example 3) In case CD5 is connected to a sensor-equipped torque wrench CSPD100N3x15D for torque management. (When controlled by sequencer).

● Setting condition

Judgement: Upper limit value: 55Nm


Lower limit value: 45Nm

Auto judgement: 0 second

Auto memory/Reset: 0 second


External input signal: rISE

- Connection: Connecting the torque sensor to "INPUT" on CD5. Terminals on CD5 should be connected to the sequencer.




● Operation

- ① As torque is applied, the peak value increases.
- ② After the sequencer receives the completion signal, it sends COMP signal to CD5 after the set timing.
- ③ As CD5 receives COMP signal, it gives judgement.
- ④ - In case of OK judgement -
When the measured value is within the set range, it output OK signal.
- In case of HI judgement
When the measured value exceeds the upper limit value, it output HI signal.
- ⑤ - In case of OK judgement -
The measured data will be saved by sending RESET signal to CD5 and the memory counter will be sent forward and reset.
- In case of HI judgement
When the sequencer receives HI signal, it outputs CLEAR signal to CD5.
As CD5 receives the CLEAR signal, the measured data will be cleared.



Case 1: Judgement OK



Case 2: Judgement HI

11. Interface to external device

11-1 Printing out

Connect CD5 and the dedicated printer (EPP16M2) with the printer cable (No.382).
Set the communication format to "Prn" and do other settings in line with the printer.

- EPP16M2 communication setting

Data format : RS232C compliant

Communication method: asynchronous

Baud rate: 2400 bps

Data length: 7 bit

Stop bit: 1 bit

Parity: none

- Progressive print out

Printing can be commanded by either of the following


- Press MEM key
- Input RESET signal
- By auto memory/reset function

* In this printing, statistical result will not be printed.


- Continuous printing

- ① Use right/down key to set the memory counter to the last counter of the range you would like to print out.

Then, press MD key.




- ② Use right/down key to set the memory counter to the first counter of the range you would like to print out. Then, press MD key.




- ③ Press MEM key.

Selected range of the measured data will be printed out (Measured data, Sample quantity = n, max value = HI, minimum value = LO, average value = x).

- Continuous printing sample
In case of memory mode 1000



In case of memory mode 99



- ※ Even in memory mode 1000, judgement result will not be printed if judgement function is not activated.
Maximum value, minimum value, average value are calculated based on the absolute value. The average value will be shown as a positive figure.
“===” will be shown when CD5 display shows either “0” or “_____”, which are excluded from computing factors and will not be printed.

11-2 PC communication

Connect CD5 and an external device by the communication cable (No.383). Set the communication format to "PC", and do other settings in line with the external device.

● Communication setting

Data format: RS232C compliant
 Communication method: asynchronous
 Baud rate: 2400/4800/9600/19200 bps
 Data length: 7 bit/ 8 bit
 Stop bit: 1 bit
 Parity: none/even/odd

① Progressive print out

Printing can be commanded by either of the following


- Press MEM key
- Input RESET signal
- By auto memory/reset function
- Send "M3CRLF" command from PC

② Printing selected range of data


Set the memory counter to the last counter of the range you would like to print out and press MD key. The display should show "Stt". Use right/down key to set it the first counter of the range and press MD. While the display shows "n", press MEM key, then printing starts.

● PC output format

In memory mode 1000



• In memory mode 99



When the value on CD5 display is "_____", 0 will be output.

● PC input command

In measuring condition, input the following command from an external device.

M	0	CR	LF
---	---	----	----

Displayed data will be output continuously every 100ms.

M	1	CR	LF
---	---	----	----

1 measured data will be output (Automatic data output will be cancelled).

M	2	CR	LF
---	---	----	----

Automatic data output will be cancelled.

M	3	CR	LF
---	---	----	----

Same as RESET signal input. In peak mode, measured data will be output, the data will be saved and the counter proceeds to the next.

M	4	CR	LF
---	---	----	----

Same as CLEAR signal input. When the peak value is displayed, the peak value will be cleared. In RUN mode, auto zero adjustment will be conducted.

M	5	CR	LF
---	---	----	----

Same as COMP isignal input in PEAK mode. It gives judgement for the displayed value.

Judgement continues until other key operation or input of RESET or CLEAR signal.

header torque value (no decimal point)

W	0	0	5	5	0	0	CR	LF
---	---	---	---	---	---	---	----	----

changes upper limit value

header torque value (no decimal point)

W	1	0	4	5	0	0	CR	LF
---	---	---	---	---	---	---	----	----

changes lower limit value

* Upper/lower limit value cannot be set in loaded condition.

* Upper/lower limit value to be transfereed should not include the figures below decimal point, which should be the same as CD5 display.

Example) When the decimal point on CD5 is set as "000.00", upper limit value 50N.m should be transferred as "W005000CRLF". If the decimal point is "0000.0", the upper value 50N.m should be "W000500CRLF".

● Response commpand

When receiving input command, following response cord will be returned.

E	0	0	CR	LF
---	---	---	----	----

receive complete

E	1	0	CR	LF
---	---	---	----	----

receive error

E	0	9	CR	LF
---	---	---	----	----

auto zero adjustment does not work (Err9)

12. Option




- Dedicated printer: EPP16M2
- Cable for printer: No.380
- PC communication cable: No.383

13. Error message

Error message	Content	How to cope
Err1~5	One of the keys are kept pushed	Turn the power off and turn it on again without touching any key. If the error disappears, you can use the product. If it stays on, switch error is suspected. Contact your nearest distributor or TOHNICHI for repair.
Err8	CPU/memory error	It needs to be repaired. Contact your nearest distributor or TOHNICHI to seek further advice.
Err9	out of allowable zero range (error on torque sensor or internal circuit.)	Check the torque sensor is securely connected. If it is not connected, connect it and press C key. If it is connected, press C key at no load condition. If the error message disappears, you can use the product. If it stays on, the sensor error or internal circuit malfunction is suspected. Contact your nearest distributor or TOHNICHI for repair.

14. Specifications

Analog part	
Voltage	DC 5V
Signal input range	-3.0mV/V ~ 3.0mV/V
Analog filter	150Hz
AD converter	16 bit successive converting style
Sampling speed	4000 times/sec
Accuracy	
Nonlinearity	±0.05% F.S
Zero point drift	±0.1 μV/ °C(TYP.)
Gain drift	±0.01%/ °C(TYP.)
Display part	
Display	Negative type liquid crystal
Torque display	13mm 6 digit
Counter display	5.2mm 4 digit
▼ display	PEAK、RUN、A. R、A. C、SET、LOCK
Max torque display	25000
Gain calibration	
Calibration methods	Equivalent input calibration
	Calibration by actual weight
	Calibration using sensor-equipped torque wrench
External connection	
External input	RESET/CO MP/CLEAR /CHSW
External output	HI/OK/LO
Analog output	Max ±11V
Communication	RS232C compliant
Power	AC100-240V±10%
Operating environment	
Temperature	0~40°C
Humidity	Below 85% RH (no condensation)
Appearance	
Dimensions	150W X 190D X 94H
Weight	About 1.8 kg



●本社

TEL.03-3762-2451 (代表) FAX.03-3761-3852
〒143-0016 東京都大田区大森北 2-2-12

●東京営業所

TEL.03-3762-2452 FAX.03-3761-3852
〒143-0016 東京都大田区大森北 2-2-12
E-mail: sales@tohnichi.co.jp

●大阪営業所

TEL.06-6374-2451 FAX.06-6374-2452
〒531-0074 大阪市北区本庄東 2-12-1 (トルクセンター大阪)

●名古屋営業所

TEL.0561-64-2451 FAX.0561-64-2452
〒480-1112 愛知県長久手町砂子 720 (トルクセンター名古屋)

●広島営業所

TEL.082-284-6312 FAX.082-284-6313
〒732-0803 広島市南区南蟹屋 2-5-2

●九州出張所

TEL.093-513-8866 FAX.093-513-8867
〒802-0001 北九州市小倉北区浅野 1-2-39 (勤和興産浅野ビル 503 号)

■ TOHNICHI MFG. CO., LTD.

TEL: +81-(0)3-3762-2455 FAX: +81-(0)3-3761-3852
2-12, Omori-kita, 2-Chome Ota-ku, Tokyo 143-0016, JAPAN
E-mail: overseas@tohnichi.co.jp
Website: <http://tohnichi.jp>

■ N. V. TOHNICHI EUROPE S. A.

TEL: +32-(0)16-606661 FAX: +32-(0)16-606675
Industrieweg 27 Boortmeerbeek, B-3190 Belgium
E-mail: tohnichi-europe@online.be
Website: <http://www.tohnichi.be>

■ TOHNICHI AMERICA CORP.

TEL: +1-(0)847-272-8480 FAX: +1-(0)847-272-8714
677 Academy Drive, Northbrook, Illinois 60062, U. S. A.
E-mail: inquiry@tohnichi.com
Website: <http://www.tohnichi.com>

■ TOHNICHI AMERICA CORP. - Atlanta Office

TEL: +1-(0)770-944-2743 FAX: +1-(0)770-944-2735
561 Thornton Road, Suite U, Lithia Springs, Georgia 30122

■ TOHNICHI SHANGHAI MFG. CO., LTD.

东仁扭矩仪器(上海)有限公司
TEL: +86-(021)3407-4008 FAX: +86-(021)3407-4135
Rm.55 No.99 Nong 1919, Du Hui Road,
Minhang Shanghai, 201108 P.R.China

トルクのことならお気軽に、ご相談下さい

トルクのことならフリーコール

0120-169-121

URL <http://tohnichi.jp>