

Digital Torque Screwdriver Checker

MODEL DLC-G

Operating Instruction



To use this product properly and safely, please read this manual carefully before use. If you have any question about the product and its operations, please contact your nearest distributor or TOHNICHI Mfg. Co., Ltd.

Safety Precautions

Read these operating instructions carefully before use. For any questions, contact your nearest distributor or TOHNICHI Mfg. Co., Ltd. Keep these instructions for future use.



Safety symbol

This symbol indicates attention is required for your safety. When this symbol appears in these instructions, pay particular attention to your safety concerns. Take preventative measures according to the written message for appropriate operation and management.

Signal Words

A signal word accompanies the safety symbol, which indicates the level of caution for the safety of people and the appropriate use of the equipment. Signal words are classified into 3 levels: "danger", "warning" and "caution" by the degree of risk.



"Danger" Imminent danger acting as a serious obstacle.



"Warning" A potential risk of becoming a serious obstacle.



"Cautions" A potential risk of becoming an obstacle although it does not result seriously.




Warning

- Do not use the product if it is in abnormal condition such as emitting smoke, strange smells, or sounds.
Doing so may cause electric shock or fire.
Immediately turn off the power, unplug the AC adapter from the outlet, and contact your nearest distributor or TOHNICHI Mfg. Co., Ltd.
- Do not disassemble or modify the equipment.
Doing so may impair safety, reduce functionality or service life, or cause failure.
- If foreign objects or liquids such as water get inside the product, do not continue to use it. Doing so may cause electric shock or fire.
- Do not connect or disconnect the AC adapter with wet hands. Doing so may cause electric shock.
- Do not use any power source other than the one indicated (AC100V to 240V \pm 10%).
Using a power source other than the specified one may cause electric shock or fire.
- Do not use a damaged USB power cord.
Doing so may cause electric shock or fire.
Observe the following points when handling the USB power cord.
 - Do not damage, process such as lengthen, or heat.
 - Do not pull it, place heavy objects on it, or pinch it.
 - Do not forcefully bend, twist, or bundle
 - Do not use for other equipment.
- Please handle the AC adapter with care.
Incorrect handling may cause a fire.
 - Do not plug in the power supply with foreign objects such as dust attached.
 - Ensure that the power plug is inserted into the base of the blade.
- When unplugging the AC adapter from the outlet, be sure to hold the AC adapter itself.

9. Do not place the product in an unstable place or a place subject to vibration, such as on a wobbly table or in a tilted place.
This torque meter may fall and cause injury.
10. Do not install in a location where there is flammable liquid or flammable gas.
Doing so may cause electric shock or fire.
11. Be sure to use specified accessories and optional items.
Do not use any accessories or options other than those specified in this instruction manual. Doing so may cause an accident or injury.

Cautions

1. Do not put this torque meter in a place of much moisture or dust, in a place that is exposed to water or direct sunlight, or in a place where the humidity or temperature fluctuates largely. It may result in electric shock, fire, malfunction, degradation of performance, or failure.
2. Clean the AC adapter periodically. Before cleaning, disconnect the plug from the power outlet and clean the root of the plug.
3. If this torque meter is not to be used for a long time, be sure to disconnect the AC adapter from the power outlet.
4. When moving this torque meter, for safety reasons, please unplug the AC adapter from the outlet and make sure that all connection cords are disconnected. Also, do not subject it to shock or vibration.
Doing so may damage the AC adapter, power supply USB cord, or connection cord, resulting in fire, electric shock, or malfunction.
5. Do not use this tester to conduct measurements beyond its capacity. For safe and efficient operation, use this tester to measure.
the torque wrenches suited to the capacity. Measurement beyond the capacity may cause accidents or damage.
6. Check for any damaged parts. Before use, check the tester and the accessories, and make sure that it operates normally and fulfills the specified functions. Check the parts and all other portions that may affect the damage operation and installation status.
For replacement or repair of damaged parts, contact your nearest distributor or Tohnichi mfg. co., Ltd.
7. Do not touch the reverse load/overload prevention screw on the stopper plate of DLC60CN-G.
This screw is equipped to protect the torque sensor from overload and reverse load.
Loosening or tightening the screws may affect the torque measurement or cause a malfunction.



8. This product is designed exclusively for Tohnichi signal type torque drivers.
This product cannot be used to measure powered drivers or direct reading drivers.

Precautions for Use

1. The power supply voltage cannot be used other than AC100 to 240V \pm 10% as specified in this instruction manual.
2. Please use the included AC adapter and USB cable for the power supply.
3. Do not subject this measuring instrument to vibration or shock.
4. Do not use this measuring device in any environment other than the one specified in the instruction manual.
5. Please perform a start-up inspection and check the settings before use.
6. Please note that this measuring instrument may malfunction or burn out if it gets wet with water or oil.
7. Please be careful not to drop or hit this measuring instrument as it may cause damage or malfunction.
8. Please use this measuring device within the measurement range specified in the instruction manual.
9. Be sure to regularly inspect this measuring instrument.
10. Be sure to perform zero adjustments before making measurements.
11. The maximum mass of the object to be measured is 5 kg (*5 kg or less if the center of gravity of the object to be measured is not at the center of the table)

In the unlikely event that a strange odor or fire occurs during use, immediately stop using it, unplug the power from the outlet, move the torque meter to a safe location, and contact TOHNICHI Mfg. Co., Ltd.

Contents

Safety precautions	2
Usage notes	4
1. Overview	6
2. Features	6
3. Composition	7
4. Specifications	7
4-1. Common use	7
4-2. Dimensions by model	8
5. Names of each part	9
5-1. Display and operation section	9
5-2. Power supply and data communication section	10
6. Functions and operation	11
7. Various settings	15
7-1. Setting items	15
7-2. Parameter settings	16
8. Measurement method	20
8-1. Measurement preparation	20
8-2. Measurement	21
9. External output function	22
9-1. USB output	22
9-2. Output format	23
9-3. Settings from external devices	24
10. Optional items	25
11. Error message list	25

1 Outline


DLC-G model is Digital Torque Driver Line Checker exclusively for Tohnichi made signal-type torque drivers.

Easy to operate. Ideal for daily inspection of torque drivers at the line side.


Daily inspection of torque drivers can improve quality, prevent error leakage to the outside, and reduce recovery costs.

2 Features

- Easy to operate. Ideal for daily inspection of signal-type torque drivers at the line side. To use DLC-G, simply click the torque driver as usual on it.
- Equipped with a pass/fail judgment function. The judgment result is indicated by the display color (white/blue/red).
- You can see the pass/fail status (OK/NG) of the torque driver at a glance, without having to compare and consider the measured values on the display at the line side.
- Capacity 1000 data memory. USB Type-C terminal is provided for data output.
- It can be connected to a variety of PCs.
- In addition, a Free data input tool called "ExRcv (Excel Receiver)" is available for download from the Tohnichi website.



3 Components



DLC-G main unit: 1 unit




Bit: 1 piece



Hexagon socket head bolt:
1 piece



Rubber sheets: 4 pieces



USB power cable: 1

*AC adapter not included

Calibration Certificate 1 pc

Quick Start 1 pc



4 Specifications

4-1. Common Specifications

Measurement direction	Clockwise
Display	Black mask LCD (white, red, blue)
Data memory	1000 data
Statistical processing	Number of samples, maximum value, minimum value, average value
Measurement mode	RUN mode / PEAK mode
Data output	USB connector (Type-C) compatible serial communication
Reset	Manual/Auto (0.1 to 5.0 seconds, can be set)
Operating temperature range:	0 to 40°C (no condensation)
Main unit power supply	DC5V (USB Type-C terminal) *1 Power consumption 5W or less

*1 AC adapter is not included. A separately sold AC adapter (BA-7) is required.

4-2. Dimensions




Accuracy:±1% +1digit

Model			DLC60CN-G	DLC600CN-G
Torque Range	cN・m	Min.-Max.	2 - 60	20 - 600
		1digit	0.02	0.2
	kgf・cm	Min.-Max.	0.2 - 6	2 - 60
		1digit	0.002	0.02
	ozf・in	Min.-Max.	3- 80	30- 800
		1digit	0.02	0.2
	lbf・in	Min.-Max.	0.2- 5	2 - 50
		1digit	0.002	0.02
Square drive			Hexagonal socket size 6.35 Male	
Weight [kg]			approx. 0.9	

5 External View

5-1. Display and Operation Keys



① Torque display

The torque value is displayed. If the pass/fail judgment result is OK, it will be displayed in blue, if it is HI-NG or LO-NG, it will be displayed in red, and if pass/fail judgment is not performed, it will be displayed in white.

② Memory counter/upper limit display section

The memory counter or upper limit value is displayed.

③ Lower limit value display section

The lower limit value is displayed.

④ ▼ mark display area



RUN: Displayed when run mode is selected



DATA: Data mode selection display



PEAK: Displayed when peak mode is selected



SET: Setting mode selection display

⑤ Check key



"It stores the measurement data and count up the memory counter by one.

It is used as the confirmation key on the setting screen."

⑥ Memory counter advance key



The memory counter is advanced one by one or continuously to recall the measurement data.

⑦ Memory counter return key



The memory counter is reset one by one or continuously to recall the measurement data.

⑧ Clear key




In peak torque display mode, it resets the peak display value or clears the memorized measurement data. In run display mode, it performs auto zero.

⑨ Power/Data/Settings key



Turns the power on/off, recalls measurement data, and recalls parameter settings. When the display is on, press and hold for 2 seconds to turn the display off. When the display is off, press to turn the display on.

5-2. Power Source and Output



1. Power port

Connect the included power USB cable and AC adapter (sold separately) to the USB port.

2. Data communication port

Connect a USB cable (sold separately) for communication to the USB port.

6 Functions and Settings

● Measurement Mode

The DLC-G has two measurement modes.

1 Continuous display measurement (RUN mode)

"When a torque load is applied, the displayed torque increases, and when the load is released the displayed torque returns to 0.


▼ mark above RUN on the front panel is displayed. This is mainly used when calibrating the DLC-G main unit."

2 Maximum value display measurement (PEAK mode)

When a torque load is applied, the displayed torque increases. Even if the load is released, the displayed torque remains at the maximum value. ▼ mark above PEAK on the front panel is displayed.

*For information on how to switch measurement modes, please refer to "7-2. Parameter Settings."

● Pass/fail judgement and data memory

When you press the  key after a measurement in PEAK mode or when the auto memory reset is activated, a pass/fail judgment is made and up to 1000 measurement values are stored in the memory.

If the result of the pass/fail judgment is OK, it will be displayed in blue for about 0.5 seconds, and if it is HI-NG or LO-NG, it will be displayed in red for about 1 second. If the upper and lower limits are 0, no pass/fail judgment will be performed.

The pass/fail judgment will be based on the following conditions:


HI-NG: Upper limit value < measured torque

OK: Lower limit ≤ Upper limit of measured torque

LO-NG: Measured torque < Lower limit



OK: Blue display



HI-NG, LO-NG: Red display

*For how to switch the upper and lower limits, please refer to "7-2. Parameter settings."




● Auto Memory Reset


The measured value is held at its peak, and when the load is released, a pass/fail judgment is made 0.1 to 5.0 seconds later (can be set as desired), the measured value is memorized, and the memory counter value is incremented and reset.




The measured value is held at its peak, and when the load is released, a pass/fail judgment is made 0.1 to 5.0 seconds later (can be set as desired), the measured value is memorized, and the memory counter value is incremented and reset.


*For how to switch between auto memory reset and reset, please refer to "7-2. Parameter Settings."


● Statistical processing function (number of samples, maximum value, minimum value, average value)


- ① Use the   keys to display the final memory counter value for the range you want to process statistically.
- ② Press the  key once to display "dAtA".




- ③ Press the  key to display "StArt".
- ④ Use the   keys to display the first memory counter value in the range you want to process statistically.




- ⑤ Press the  key to display the number of samples in the specified range "n", the maximum value "HI", the minimum value "Lo", and the average value "Av" in that order.



- ⑥ Press the  key to return to the measurement screen.

● Reading Data









"After measurement, press the   keys to read out the memorized data.
In PEAK mode, the memory counter value and measured value are displayed."





● Data output _ sequential output

After measurement and after reading data with   key, press  key to output the data.
Data is also output when the auto memory reset is activated.

● Data output _ bulk output


- ① When the final memory counter value of the output range is displayed and the  key is pressed, "dAtA" is displayed.
- ② Press the  key to display "StArt".
- ③ Set with the   keys to the first memory counter value in the range to be output.
- ④ Press the  key five times to display "oUt-n".
- ⑤ Use the   to switch to "oUt-y" and press the  key to output all the measurement data for the selected range at once.











- ⑥ Press the  key to return to the measurement screen.


● Clearing Data _ 1 Clearing Data

After reading the data with the   keys, pressing the  key will erase the data.




● Data deletion _ bulk deletion

- ① When the final memory counter value of the output range is displayed and the  key is pressed, "dAtA" is displayed.
- ② Press the  key to display "StArt".
- ③ Use the   keys to select the first memory counter value in the range to be erased.
- ④ Press the  key six times to display "CLr-n".
- ⑤ Use the   keys to switch to "CLr-y" and press the  key to erase all the measurement data in the selected range at once.




- ⑥ After all data has been erased, the measurement screen will return.

● Auto Zero Adjustment

If the  is pressed without peak hold, the auto zero function will be activated. At this time, make sure to release the torque load.

If the torque load exceeds 5% of the maximum range, "Err9" is displayed.

If Err9 is displayed:

- Press the  key while the unit is unloaded.
 - If the Err9 message disappears, the unit can be used normally.
- If Err9 does not disappear, turn the power switch OFF and then ON again.
 - If Err9 does not disappear, there may be an error in the torque sensor or board circuit.


● Over torque alarm

If the maximum measurement range is exceeded, the displayed value will flash to protect the measuring instrument. Immediately release the load.

● Reverse Load Alarm

If a load in the opposite direction to the measurement direction is detected, the displayed value will flash to protect the instrument. Remove the load immediately.

● Auto Power Off

"If there is no key operation or communication for the set time, the display will turn off and the instrument will enter power-saving mode. Press the  key to turn the display on and start measuring."

*For information on how to switch the auto power off, please refer to "7-2. Parameter Settings."

● Error display message

The DLC-G has a self-diagnosis function that displays error messages Err1-9 when a malfunction occurs.

For a list of error messages, please refer to "Chapter 11. Error Message List."



7 Various Settings

This section explains the functions and operation methods of each setting.

For information on how to set up via communication from an external device, please refer to "9-3. Setting up from an external device."


7-1. Setting Items

	Item	Top left display	Main display	
			Default	Selection item
1	Setting item selection	— —	dAtA	SEt
2	Measurement Mode	SEL	PEAK	rUn
3	Unit Settings	USEL	cN·m	kgf·cm / ozf·in / lbf·in
4	Upper limit setting	HI	00.00	00.00 to the Maximum
5	Maximum Measurement Value	Lo	00.00	00.00 to the maximum
6	Auto Memory Reset Settings	Ar	0.0	0.1/ 0.2/ 0.3/ 0.4/ 0.5 / 1.0/ 2.0/ 3.0/ 4.0/ 5.0
7	Auto power off setting	P_oFF	10	30/60/nonE
8	Key operation sound setting	bU	on	oFF
9	Baud rate setting	bPS	115.2K	9600/19200
	Data length setting	d_LEn	8blt	7blt
	Parity Settings	PrtY	nonE	odd / EvEn
	Output Format	Formt	dF-1	dF-2/dF-3
10	Setting value default	dFLt	no	yES

7-2. Parameter Settings

● Read the setting screen






When no load is applied, pressing the  key will take you to the item selection screen.




● Setting item selection

"Select data processing ""dAtA"" or parameter setting ""SEt""."






* ""SEt"" is displayed in RUN mode."

- Use the   key to select "SEt" and press the  key or  key to proceed to parameter setting.
- Press the  key to return to the measurement display.





● Measurement mode setting (factory setting: PEAK mode)


Set the measurement mode.

- Use the   keys to select PEAK measurement mode "PEAK" or RUN measurement mode "rUn".
- When you press the  key, the data clear confirmation screen will appear.
- Pressing the  key will proceed to the next step without setting.
- Press the  key to return to the measurement display.



*When the measurement mode is changed, the measurement data memory is cleared.






- Pressing the  key switches the measurement mode, clears the memory data, and proceeds to the next mode.
- Press the  key to return to the previous display.




Data clear confirmation screen

● Unit setting (factory setting: cN·m)






Set the units.

- Use the   keys to select "cN,m" / "kgf,cm" / "ozf,in" / "lbf,in".
- Press the  key to set and proceed to the next step.
- Pressing the  key will proceed to the next step without setting.
- Press the  key to return to the measurement display without making any settings.
- Upper limit registration (factory setting: 0 cN·m)



● Upper limit registration (factory setting: 0 cN·m)






Register the upper limit for pass/fail judgment.


- Use the  key to select a digit and use the  key to adjust the value.
- Press the  key to set and proceed to the next step.
- Pressing the  key will proceed to the next step without setting.
- Press the  key to return to the measurement display without making any settings.
- ※ If you attempt to register a value that exceeds the measurement range, "SEtErr" will be displayed and you will be prompted to register the upper limit value again.
- ※ Please set the upper limit value higher than the lower limit value.



● Lower limit registration (factory setting: 0 cN·m)






Register the lower limit for pass/fail judgment.

- Use the  key to select a digit and use the  key to adjust the value.
- Press the  key to set and proceed to the next step.
- Pressing the  key will proceed to the next step without setting.
- Press the  key to return to the measurement display without making any settings.
- ※ If you attempt to register a value that exceeds the measurement range, "SEtErr" will be displayed and you will be prompted to register the upper limit value again.
- ※ Please set the upper limit value higher than the lower limit value.



● Auto memory reset setting (factory setting: 0.0 seconds)






Sets the auto memory reset time.



- Use the   keys to return to the measurement display without setting.
- ※ If set to "0.0", auto reset will not function.
- Press the  key to set and proceed to the next step.
- Press the  key to proceed to the next step without setting.
- Press the  key to return to the measurement display without setting.



● Auto power off setting (factory setting: 10 minutes)






Sets the auto power off time.



- Use the   keys to select 10 minutes ("10"), 30 minutes ("30"), 60 minutes ("60"), or none ("nonE").
- Press the  key to set and proceed to the next step.
- Press the  key to proceed to the next step without setting.
- Press the  key to return to the measurement display without setting.



● Key operation sound setting (factory setting: on)






Sets whether or not the key operation sound is sounded. Even if set to "oFF", the overtorque alarm will sound.



- Use the   keys to select "on" or "oFF".
- Press the  key to set and proceed to the next step.
- Press the  key to proceed to the next step without setting.
- Press the  key to return to the measurement display without setting.



● Baud rate setting (factory setting: 115.2Kbps)






Set the communication baud rate.



- Use the   keys to select "115.2K" / "9600" / "19200".
- Press the  key to set and proceed to the next step.
- Press the  key to proceed to the next step without setting.
- Press the  key to return to the measurement display without setting.



● Data length setting (factory setting: 8bit)






Set the communication data length.


- Use the   keys to select "8bit" or "7bit".
- Press the  key to set and proceed to the next step.
- Press the  key to proceed to the next step without setting.
- Press the  key to return to the measurement display without setting.



● Parity setting (factory setting default: none)






Sets the communication parity.




- Use the   keys to select none (nonE), even (EvEn), or odd (odd).
- Press the  key to set and proceed to the next step.
- Press the  key to proceed to the next step without setting.
- Press the  key to return to the measurement display without setting.



● Output format setting (factory setting: dF-1)






Set the output format. For details, refer to "9-2. Output format".



- Use the   keys to select "dF-1" / "dF-2" / "dF-3".
- Press the  key to set and proceed to the next step.
- Press the  key to proceed to the next step without setting.
- Press the  key to return to the measurement display without setting.



● Setting defaults

Returns the settings to the factory defaults.

- Select "yES" with the   keys and press the  key to erase all measurement data and reset all settings to their factory defaults.
- Press the  or  key to return to the measurement display.




8 Measurement


8-1. Preparation for Measurement

- ① Place the DLC-G on a level surface.


※ If the installation location is slippery, secure the DLC-G base to the DLC-G installation location with screws and nuts, or attach a rubber sheet to the back of the base.



- ② Attach the included bit to the DLC-G main unit and secure it with the included hexagonal screw.




- ③ Connect the included USB power cable to the USB power port on the side of the DLC-G main unit, and connect the AC adapter (sold separately) to an outlet. (Leave the unit for at least 30 minutes after turning on the power.)
- ④ Select the measurement mode to "PEAK mode."
- ⑤ Set various settings such as upper and lower limits, auto memory reset settings, and communication settings.





8-2. Measurement Object Installation

The measurement operation is explained with reference to the following setting example.



SEL	Measurement mode setting	PEAK mode
HI	Upper limit setting	100.0 cN·m
Lo	Lower limit setting	50.0 cN·m
Ar	Auto memory reset settin	0.5 seconds

- ① With no load, perform auto zero adjustment with the  key.
- ② Check the set torque of the torque driver.



- ③ Set the torque driver and apply a load until it clicks.
- ④ After clicking, release the load on the torque driver.
- ⑤ After 0.5 seconds (set value) after releasing the load, the auto memory reset function will perform a pass/fail judgment.


※ If the auto memory reset setting is 0.0 seconds, pressing the  key will perform a pass/fail judgment.



- ⑥ If the pass/fail result is OK, it will be displayed in blue for approximately 0.5 seconds, and if it is HI-NG or LO-NG, it will be displayed in red for approximately 1 second.

※ If both the upper and lower limits are 0 cN·m, no pass/fail judgment will be made.


- ⑦ After a pass/fail judgment is made, the data is memorized, the memory counter value is incremented by one, and the peak torque value is reset.
- ⑧ Repeat steps ③ to ⑥ as many times as required.



9 External Output Function

9-1. USB Output

- Connect the DLC-G to an external device with a communication cable (catalog No. 586 or No. 587).
- Set the communication settings to match those of the external device. (For setting instructions, refer to "Chapter 7: Various Settings.")
- If you want to communicate using a USB cable, you will need to install a dedicated driver, which can be downloaded from the Tohnichi website.
(<https://www.tohnichi.co.jp/products/detail/304>)



● Communication settings

Data format: RS232C compliant

Transmission method: Asynchronous serial

Baud rate: 115.2K/19200/9600 bps

Data length: 8bit/7bit

Stop bit: 1bit

Parity: None/Even/Odd

9-2. Output Format

When dF-1 is set (TDT3 memory mode 1000 compatible format)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
R	E	,	0	0	0	1	,	SP	0	6	0	0	.	0	,	SP	,	O	K	CR	LF
Header		Memory counter					*1 Polarity		Torque data				*3 Fixed data			*2 Judgment result		Delimiter			

*1 Polarity (measurement direction): SP (blank) when measuring on the right, "-" when measuring on the left.

*2 Judgment result: "O K" for OK, "H I" for HI-NG, "L O" for LO-NG, "-" if no judgment is made.

*3 Fixed value: Fixed value due to compatibility format with other products.

When dF-2 is set (LC3 M1000_PC1 compatible format)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
R	E	,	0	0	0	1	,	SP	6	0	0	.	0	,	SP	,	O	K	,
Header		Memory counter					*1 Polarity		Torque data				*3 Fixed data			*2 Judgment result			

21	22	23	24	25	26	27	28	29	30	31	32	33
0	0	/	0	0	,	0	0	:	0	0	CR	LF
**3 Fixed data				*3 Fixed data				Delimiter				

*1 Polarity (measurement direction): SP (blank) when measuring on the right, "-" when measuring on the left.

*2 Judgment result: "O K" for OK, "H I" for HI-NG, "L O" for LO-NG, "-" if no judgment is made.

*3 Fixed value: Fixed value due to compatibility format with other products.

When dF-3 is set (Tohnichi standard format)

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
R	E	,	0	0	1	,	+	6	0	0	.	0	,	c	n	m	SP	SP	,
Header		*1 Memory counter				*2 Polarity		Torque data				*5 Torque unit							

21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
SP	0	0	0	,	d	e	g	,	O	-	,	1	2	3	4	5	6	A	,
*4 Fixed data				*4 Fixed data				*3 Judgment result		Serial number									

41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59
0	0	/	0	0	/	0	0	,	0	0	:	0	0	:	0	0	CR	LF
*4 Fixed data								*4 Fixed data								Delimiter		

	15	16	17	18	19
cN·m	c	n	m	SP	SP
kgf·cm	k	g	f	c	m
ozf·in	o	z	f	i	n
lbf·in	l	b	f	i	n

*5 Torque unit:

Depending on the unit setting, it will look like the table above.

*1 Memory counter: When the memory counter is 1000, it becomes "000".

*2 Polarity (measurement direction): When measuring to the clockwise, it becomes "+", when measuring to the counter clockwise, it becomes "-".

*3 Judgment result: When OK, it becomes "O-", when HI-NG, it becomes "H-", when LO-NG, it becomes "L-", and when no judgment is made, it becomes "-".

*4 Fixed value: It is a fixed value because it is a format compatible with other products.

9-3. Setting from an External Equipment

You can change the settings of the DLC-G by inputting commands from an external device.

When changing settings via command communication, be sure to do so with no torque load.

When sending two or more settings in succession, wait at least 200 ms after receiving a response before sending the next command.


When the DLC-G receives a command, it executes it and returns a response command.

Command list

Communication command	Action/content	Remarks
AT037, * * * * *, * * * * *	Registers upper and lower torque limits simultaneously. The * indicates a 5-digit torque value including a decimal point. Send the upper and lower torque limits in that order.	Send a value within the measurement range for the upper torque limit or higher than the lower torque limit. (0 can be set)

- * All commands are in ASCII code
- * Add CRLF to the end of the command.

Response command	Contents
RE003,OK	Receiving complete
RE004,ERROR	Receiving error. Setting value error
E10	Receiving error. Setting value error *Error when "AT" is not added to the beginning of the transmission command



10 Optional Accessories

- ① USB cable
 - Type-C ⇔ Type-C Catalog No.586
 - Type-C ⇔ Type-A Catalog No.587
- ② AC Adapter
 - BA-7
- ③ Calibration kit
 - DLCTCL60CN (Applicable model : DLC60CN-G)
 - DLCTCL600CN (Applicable model : DLC600CN-G)

11 Error Message

Error Message	Indication	Solution
Err1 - 5	Operation key is continuously pushed.	<p>Turn off the power once and turn it on without touching any keys.</p> <p>If Err disappears, it should work properly.</p> <p>If Err does not disappear, it needs to be repaired.</p> <p>Please contact TOHNICHI or your nearest distributor.</p>
Err8	CPU / Memory error	<p>It needs to be repaired. Please contact TOHNICHI or your nearest distributor.</p>
Err9	Torque zero range over Malfunction of the torque sensor or circuit board.	<p>Push C key at no loading condition.</p> <p>If Err 9 disappears, it should work properly.</p> <p>If Err 9 does not disappear, it needs to be repaired.</p> <p>Please contact TOHNICHI or your nearest distributor.</p>

Designs and specifications are subject to change without notice.

■ **Tohnichi Mfg. Co., Ltd.**

Tel. +81-3-3762-2455

2-12, Omori-Kita, 2-Chome Ota-ku, Tokyo Japan

E-mail: overseas@tohnichi.co.jp

Website: <http://www.global-tohnichi.com>

■ **Tohnichi America Corp.**

Tel. +1 847 947 8560

1303 Barclay Blvd. Buffalo Grove, IL 60089 USA

E-mail: inquiry@tohnichi.com

Website: <http://tohnichi.com>

■ **Tohnichi Shanghai Mfg. Co., Ltd.**

东仁扭矩仪器（上海）有限公司

Tel. +86 21 3407 4008 Fax. +86 21 3407 4135

RM.5 No.99 Nong1919, Du Hui Road, Minhang,
Shanghai, P.R. China

■ **Tohnichi Europe Technical Support Office (TETSO)**

TEL. +49 2131 7514753

Hellersbergstrasse 12A 41460 Neuss Germany

E-mail: europe@tohnichi.com

■ **Tohnichi Asia Technical Support Office (TATSO)**

TEL. +66 33 002307 FAX. +66 33 002337

271/184 Moo 6, Tambon Borwin, Amphur Sriracha,
Chonburi, 20230 Thailand

E-mail: tatso@tohnichi.com

